



LCP 102 Graphical Local Control Panel

- Multi-language display
- Status messages
- Quick menu for easy commissioning
- Parameter setting and explanation of parameter function
- Adjusting of parameters
- Full parameter backup and copy function
- Alarm logging
- Info button – explains the function of the selected item on display
- Hand-operated start/stop, or Automatic mode selection
- Reset function
- Trend graph

Ordering number	VLT® HVAC Drive	VLT® AQUA Drive	VLT® AutomationDrive	
	FC 102	FC 202	FC 301	FC 302
130B1107	●	●	●	●



LCP 101 Numerical Local Control Panel

The numerical control panel offers an excellent MMI interface to the drive.

- Status messages
- Quick menu for easy commissioning
- Parameter setting and adjusting
- Hand-operated start/stop function or Automatic mode select
- Reset function

Ordering number	VLT® HVAC Drive	VLT® AQUA Drive	VLT® AutomationDrive	
	FC 102	FC 202	FC 301	FC 302
130B1124	●	●	●	●



LCP Panel Mounting Kit

All ordering numbers are for IP55/66 and include fasteners and a gasket.

Ordering number	VLT® HVAC Drive	VLT® AQUA Drive	VLT® AutomationDrive	
	FC 102	FC 202	FC 301	FC 302
130B1113 With fasteners, gasket, graphical LCP and 3 m cable	●	●	●	●
130B1114 With fasteners, gasket, numerical LCP and 3 m cable	●	●	●	●
130B1117 With fasteners and gasket and without LCP and with 3 m cable	●	●	●	●
130B1129 With fasteners, gasket, blind cover and 8 m "free end" cable	●	●	●	●
130B1170 With fasteners and gasket and without LCP and with 3 m cable	●	●	●	●