

NP8-□□ ZS/□□	Model	Color	↵	↶
	NP8-02ZS/24	●	—	2
	NP8-11ZS/24	●	1	1

★  $\phi$  30 Mushroom button stay-up.rotated to reset (Non-illuminated)

NP8-□□ ZS/□□	Model	Color	↵	↶
	NP8-10ZS/34	●	1	—
	NP8-01ZS/34	●	—	1

★  $\phi$  30 Mushroom button stay-up.rotated to reset (Non-illuminated)

NP8-□□ ZS/□□	Model	Color	↵	↶
	NP8-20ZS/34	●	2	—
	NP8-02ZS/34	●	—	2
	NP8-11ZS/34	●	1	1

★ Double-headed flush momentary button (Non-illuminated)


NP8-□□ S	Lamp-Voltage	Model	Color	↵	↶
	Non-illuminated	NP8-20S	●+●	2	—
		NP8-02S	●+●	—	2
		NP8-11S	●+●	1	1

★ Double-headed flush momentary button (Illuminated)

NP8-□□ SD	Lamp-Voltage	Model	Color	↵	↶
	LED: AC/DC 6V, 12V, 24V, 36V; AC 110V ~230V	NP8-20SD	●+●	2	—
		NP8-02SD	●+●	—	2
		NP8-11SD	●+●	1	1

Dimension (mm)

Dimension (mm)



Dimension (mm)

Dimension (mm)

